



**instruction
manual
for QSA SERIES
LOW POWER
LOW VOLTAGE
POWER SUPPLIES**

OFFICIAL RECORDS STATION
FILE COPY
FACILITIES

FEB 28 1975

S O R E N S E N C O M P A N Y

A UNIT OF RAYTHEON COMPANY

676 ISLAND POND ROAD MANCHESTER, NEW HAMPSHIRE 03103



**instruction
manual**

**for QSA SERIES
LOW POWER
LOW VOLTAGE
POWER SUPPLIES**

(MODELS 5-6.4, 10-1.4, 10-2.2, and 10-3.7)

SORENSEN COMPANY

A UNIT OF RAYTHEON COMPANY

676 ISLAND POND ROAD MANCHESTER, NEW HAMPSHIRE 03103

WARRANTY

Sorensen Company warrants all parts of equipment of its manufacture, except special purpose tubes and semi-conductor devices which carry their own manufacturer's warranty, to be free from defects caused by faulty material or poor workmanship. Sorensen Company warrants its products to conform to applicable commercial or military specifications when confirmed on the Order Acknowledgment form to be free from defects caused by faulty material or poor workmanship. Sorensen Company's obligation is limited under the warranty to repair or replacement of products in kind, or at its sole option to issuance of a credit of original purchase price. Returns must be accompanied by a Sorensen Company Return Authorization form and conform to standard conditions for adjustment. The aforesaid warranty shall expire twelve (12) months following the last day of the month of shipment from Sorensen Company's plant. The foregoing states the entire warranty extended by Sorensen Company. No other warranty, expressed or implied, is made and, specifically, Sorensen Company makes no warranty of merchantability or fitness for any purpose. In no case shall Sorensen Company be liable for any special or consequential damages. Authorization must be obtained prior to return of defective items.

SORENSEN COMPANY

TABLE OF CONTENTS

Para No.

Page No.

Section I. Introduction and Description

1-1.	Introduction	1-1
1-4.	Description	1-1
1-8.	Remote Sensing	1-2
1-9.	Remote Programming	1-6
1-10.	Series Operation	1-6
1-11.	Parallel Operation	1-7
1-12.	Current Limit/Foldback	1-7
1-13.	Optional Accessories	1-8

Section II. Preparation for Use

2-1.	General	2-1
2-3.	Inspection	2-1
2-5.	Input Connections	2-2
2-7.	Electrical Check	2-3
2-9.	Mounting	2-3

Section III. Operating Instructions

3-1.	General	3-1
3-3.	Controls	3-1
3-5.	Preoperation Consideration	3-1
3-6.	Current/Temperature Compensation	3-1
3-9.	Current-Limit Reset	3-2
3-10.	Current-Foldback Reset	3-3
3-11.	Local Sensing	3-3
3-14.	Remote Sensing	3-4
3-16.	Remote Programming	3-4

Para No.		Page No.
3-17.	Resistance.	3-4
3-20.	Voltage , , ...	3-7
3-21.	Series Operation	3-7
3-25.	Parallel Operation	3-8

Section IV. Principles of Operation

4-1.	General.	4-1
4-3.	Passing-Stage Principle.	4-1
4-5.	Block Diagram	4-1
4-7.	Detailed Discussion	4-3
4-8.	Reference Power Supply	4-3
4-11.	Sensing and Error-Amplifier Section	4-4
4-13.	Drivers and Passing Stage	4-4
4-14.	Current-Limit Section	4-5
4-16.	Current-Foldback Section	4-5
4-18.	Reverse-Bias Section	4-6

Section V. Maintenance

5-1.	General.	5-1
5-3.	Periodic Servicing	5-1
5-5.	Troubleshooting	5-1
5-7.	Calibration	5-3
5-9.	Performance Testing	5-7
5-10.	Output Ripple.	5-7
5-11.	Regulation	5-9

Section VI. Replacement Parts List

6-1.	General.	6-1
6-3.	Manufacturer Coding	6-1
6-5.	Ordering Parts	6-2

LIST OF ILLUSTRATIONS

Fig. No.		Page No.
1-1.	Current Derating	1-2
1-2.	Current Limit Characteristic (typical)	1-6
1-3.	Current Foldback Characteristics	1-7
2-1.	Input Connections	2-2
2-2.	Knockout Dimensions	2-4
2-3.	SR5 Rack Adapter	2-5
2-4.	SR6 Rack Adapter	2-6
3-1.	Remote Sensing	3-5
3-2.	Remote Programming With Remote Sensing	3-6
3-3.	Series Operation	3-9
3-4.	Parallel Operation	3-11
4-1.	Series Passing Stage Principle	4-2
4-2.	Block Diagram	4-3
5-1.	Typical Component Board (QSA 10-3.7 shown)	5-3
5-2.	Partial Disassembly (typical)	5-4
5-3.	Schematic Diagram	5-5/6
5-4.	Performance Test Setup	5-8

LIST OF TABLES

Table No.		Page No.
1-1.	Unit Specifications (Sheet 1 of 3)	1-3
	(Sheet 2 of 3)	1-4
	(Sheet 3 of 3)	1-5
3-1.	Rectifier Recommendations, Series Operation.	3-8
5-1.	Troubleshooting Data	5-2
6-1.	Replacement Parts List (Sheet 1 of 3)	6-3
	(10-volt Models) (Sheet 2 of 3)	6-4
	(Sheet 3 of 3)	6-5
6-2.	Replacement Parts List (Sheet 1 of 2)	6-6
	(Model 5-6.4) (Sheet 2 of 2)	6-7

SECTION I

INTRODUCTION AND DESCRIPTION

1-1. INTRODUCTION.

1-2. This manual provides operation and maintenance instructions for the Models QSA 5-6.4, 10-1.4, 10-2.2, and 10-3.7 voltage-regulated power supplies, manufactured by the Sorensen Company.

1-3. The manual is divided into six sections. Section I contains a description of the units, as well as unit characteristic curves and a tabular listing of complete unit specifications. Details on initial inspections and checkout procedures are given in Section II. Operating instructions, including methods for adapting units to various applications, comprise Section III. Sections IV and V provide the principles of operation and maintenance procedures, respectively. A replacement parts list forms Section VI.

1-4. DESCRIPTION.

1-5. The units provide a highly regulated (voltage) d-c output and are designed to accept any of three separate, single-phase a-c inputs. (For complete unit specifications, refer to Table 1-1.) They also offer extremely fast recovery times as well as characteristically low output impedances.

1-6. A wide selection of mounting positions is a unique feature. The units may be end, bottom or side mounted, using tapped holes in the enclosures. Finished with a black, baked-on, mar-resistant, wrinkle coating, these enclosures serve not only as protective housings but also as heatsinks. This latter feature eliminates the need for an external heatsink.




Figure 1-1. Current Derating

1-7. Operational features include remote sensing, programming, and series and parallel operation. In addition, each unit has either a current-limiting system or a current-foldback arrangement.

1-8. REMOTE SENSING. Provisions are incorporated in the unit for extending the output regulating point from the unit output terminals to

QSA MODELS				
	5-6.4	10-1.4	10-2.2	10-3.7
Input Ratings	105 - 125 / 200 - 240 / 210 - 250 50 - 480 1			
Voltage ranges (Vac)				
Frequency range (Hz)				
Phase				
Max. current (Aac)				
115 Vac input	1.6	0.6	0.8	1.4
230 Vac input	0.8	0.3	0.4	0.7
Power factor (typical) (1)	0.84	0.84	0.83	0.83
Efficiency (typical) (%) (1)	30	29	35	39
Output Ratings				
Voltage range (Vdc)	3 - 7	0 - 10		
Resolution (typical) (mV)	22	28		
Current range at 50°C (2) (A _{dc})	0-6.4	0 - 1.4	0 - 2.2	0 - 3.7
Current Limit or Foldback Characteristics	Fig. 1-3	Fig. 1-2.		
(1) At nominal input and full rated output				
(2) See Figure 1-1 for current derating characteristics				

Table 1-1. Unit Specifications (Sheet 1 of 3)

QSA MODELS				
	5-6.4	10-1.4	10-2.2	10-3.7
Regulation (3)	$\pm 0.01\%$	$\pm 0.005\%$ or $\pm 0.2 \text{ mV}^{(4)}$		
Ripple Voltage (50-60 Hz) RMS Peak-to-Peak	300 μV 3 mV			
Transient Response (typical) (5)	20 μs			
Temperature Coefficient	0.015%/°C	0.01%/°C or 0.5 mV/°C (4)		
Output Voltage Turn-on and Turn-off Overshoots	None			
Ambient Temperature Range	-20°C - +71°C	0 - 71°C		
Remote Programming Resistance Voltage Signal	100 ± 0.5 ohms/volt 1 volt/volt			
(3) For combined load and line				
(4) Whichever is greater				
(5) For a step load change NL to FL, or FL to NL, and recovery to within a $\pm 10 \text{ mV}$ band				

Table 1-1. Unit Specifications (Sheet 2 of 3)

	QSA MODELS		
	5-6.4	10-1.4	10-2.2
Output Impedance	R + jwL		
R (μ ohms)	50	300	200
L (μ h)	0.2	0.2	0.2
Stability (6)	0.025%/8 hours		
Maximum Output - Series Connected System	2 units	20 units	
Parallel Operation	See Para. 3-26		
Remote Sensing Compensation (Max.)	1.5 volts/load lead		
Cooling	Convection		
RFI Characteristics (typ)	Meets Mil-I-6181 and Mil-I-16910		
Envelope Dimensions (in.)	5-1/8 3-5/16 9-1/2	3-7/8 3-5/16 6-1/2	5-1/8 3-5/16 9-1/2
Weight (lb)	10	5	8
(6) 8 hours after warm-up and with constant load, line and ambient temperature			

Table 1-1. Unit Specifications (Sheet 3 of 3)

the load. This feature, known as remote sensing, compensates for a maximum of 1.5 volts IR drop in each load line.

1-9. REMOTE PROGRAMMING. The unit is locally programmed, i.e., its output voltage is altered by rotation of the Output Adjust Control. To service those applications where it is desirable to maintain remote control over unit output, an arrangement for remote programming has been incorporated into unit design. This provision permits the introduction of a resistor (or a signal voltage) into the voltage adjust circuit to provide a precalculated output. Resistance-programming sensitivity is 100 ± 0.5 ohms/volt; sensitivity for voltage signal programming is 1 volt/volt. Refer to para. 3-16.

1-10. SERIES OPERATION. For applications requiring output voltages higher than any single QSA can supply, a number of QSA units may be connected in series. Regulation in series operation is the sum of the regulations for all units. Refer to para. 3-21.




Figure 1-2. Current Limit Characteristic (typical)

1-11. PARALLEL OPERATION. Parallel operation may be used to service those applications requiring a higher output current than any single QSA can provide. Paralleling is indirect through a "master-slave" approach. The maximum number of units which may be paralleled is discussed in para.3-26.

1-12. CURRENT LIMIT/FOLDBACK. The 10-volt supplies described herein contain a safety feature which prevents damage in the event of overload. As the loading increases, the current output rises to a maximum safe limit. Thereafter, the current will rise no higher, even though the load may be increased to the point of short-circuit. In the Model 5-6.4 supply, the output current actually decreases as the load is progressively increased beyond the maximum safe point.




Figure 1-3. Current Foldback Characteristic - Model 5-6.4

1-13. OPTIONAL ACCESSORIES.

1-14. Two rack-mount adapters are offered as optional accessories to the QSA line. Designated SR5 and SR6, both are designed for standing 19-in. racks and both are only 3-1/2 in. in height. Either will hold four QSA 10-1.4 power supplies, or three power supplies - in any combination - of the four models described here. Both adapters provide for mounting optional meter-panels (see Data Sheet DC201, QSA Series) or over-voltage accessories (Model VP-1). The adapters have optional screw-mounted front panels which add to the appearance of the installation while still allowing ready access to the units if terminal board alterations are necessary. In addition, the SR6 construction allows units to be mounted at the front or rear of the adapter and incorporates optional standard relay-rack slides at each side.

1-15. The QSA line will also mount on 5-1/4 in. rack-mount adapters SR3 and SR4. The SR4 is designed to accept relay-rack slides (not identical to those on SR6). Optional meter-panels are also available. (See Data Sheet DC201).

SECTION II

PREPARATION FOR USE

2-1. GENERAL.

2-2. After unpacking, initial inspections and preliminary checkout procedures should be performed to assure that unit is in good working order. Basically, these consist of visually checking for damaged parts and components, and of making an electrical check. If it is determined that the unit is damaged notify the carrier immediately. The carrier's claim agent will then prepare a report of damage. The user is required to send this report to the Service Dept., Sorensen Company, 676 Island Pond Road, Manchester, New Hampshire, 03103. Sorensen Company will advise the user as to what action is required to repair or replace the supply.

2-3. INSPECTION.

2-4. Check for damage incurred during shipment as follows:

- a. Inspect enclosure for dents, chips, etc.
- b. Check condition of external terminal board. Make certain that all screws are in place and that links are fitted over the barrier strips between the positive OUT terminal (1) and its adjacent SENSE terminal (2) and across the negative OUT terminal (4) and its adjacent SENSE terminal (3).
- c. Using a slotted-drive screwdriver, rotate Output Adjust (adjust-access aperture located in nameplate) from stop-to-stop, and turn fully counterclockwise. Rotation should be smooth through a 300-degree angle.

d. Remove four screws retaining side enclosure plate, and inspect component board.

e. Remainder of enclosure may be removed by removing mounting screws and hex-head screws at nameplate end. Inspect transformer, capacitors and passing-stage transistors.

Note

A guide pin, located at closed end of enclosure, should be used to align enclosure and chassis when reassembling unit. Tighten cap screws to 25 lb-in.

2-5. INPUT CONNECTIONS.

2-6. If either of the two alternatives to a nominal 115-Vac input is to be used, change transformer T1 primary tap wiring as indicated in Figure 2-1. The factory-wired 115-Vac configuration is included to facilitate reconversion to this input, if such action becomes desirable at some future date. Remount enclosures following inspection or tap changing.

Note

Fuse the input if it is desired to protect the power transformer and rectifiers from excessive current caused by certain types of unit malfunction. Recommended fuse is Bussman Type 3AG or equivalent in the following sizes:

Input	5-6.4	10-1.4	10-2.2	10-3.7
115 Vac	2.0 A	0.75 A	1.0 A	1.5 A
220/230 Vac	1.0 A	0.375 A	0.5 A	0.75 A




Figure 2-1. Input Connections

2-7. ELECTRICAL CHECK.

2-8. To perform an initial electrical check, proceed as follows:

a. Make certain unit is located in an area where free passage of air is unrestricted; then connect input leads to terminals 6 and 7 (IN) on unit terminal board. Use terminal 5 (GRD) for input system ground.

b. Connect a d-c voltmeter across terminals 1 and 4 (OUT). Select at least a 10 V range.

c. Apply nominal input power.

d. Rotate Output Adjust from stop-to-stop. Voltmeter indicator should swing from 0 to 10 V (3-7 V if model 5-6.4).

e. Remove input power.

2-9. MOUNTING.




2-10. As previously mentioned, the units may be mounted in a variety of positions and locations, including a rack. Figure 2-2 illustrates the mounting-hole and knock-out dimensions for end, side and bottom mounting. Use No. 8-32 screws for mounting. In determining the length of screws to be used, consider washer and mounting-surface thickness and the 3/8 in. required for maximum thread engagement. When using nameplate-end mounting, place 1/4-in. spacers over mounting holes between unit and mounting surface.

CAUTION

Knockouts are required for proper dissipation of heat generated by supply. Do not reduce knockout dimensions, nor impede natural flow of air around supply.

Note

If it is expected that unit will be subjected to shock or vibration during operation, do not use nameplate-end mounting.




DIMENSION CHART

QSA SERIES	A	B	C	D	E
10-1, 4	4-1/4	5-11/16	5-1/8	2-3/8	2-7/8
10-2, 2	4-1/4	5-11/16	5-1/8	3-5/8	4-3/8
5-6, 4	4-1/4	8-11/16	8-1/8	3-5/8	4-3/8
10-3, 7	4-1/4	8-11/16	8-1/8	3-5/8	4-3/8


NOTE: ALL DIMENSIONS ARE IN INCHES

Figure 2-2. Knockout Dimensions



NOTE: ANY COMBINATION OF 3 MODULES.

Figure 2-3. SR5 Rack Adapter



- NOTES:
1. SR6 RACK ADAPTER WILL BE DISMANTLED FROM 10-1, A, MODULES AS KIT IS DISMANTLED FROM 10-1, A, MODULES.
 2. SLIDES IN SR6 RACK SHOULD BE REASSEMBLED FROM 10-1, A, MODULES, SLIDES, AND 10-1, A, MODULES.

Figure 2-4. SR6 Rack Adapter, Top View

2-11. If the units are to be rack mounted in the SR5 optional adapter (Figure 2-3), remove adapter face plate, position unit behind adapter and then secure with hardware enclosed in bag tied to adapter handle. Fit adapter to rack and attach. Make necessary input connections (para.2-5), check electrically per para.2-7, and adapt unit to desired application (Section III) before installing face panel.

2-12. If optional SR6 adapter is to be used for rack mounting (Fig.2-4), first remove face panel, if units are to be mounted to front chassis. Next, mount units on front or rear of adapter, using hardware removed from bag tied to handle. Slide adapter into rack, attach, and then make necessary input connections (para. 2-5), electrical checks (para.2-7), and output adjustment (Section III) before installing face panel.

SECTION III

OPERATING INSTRUCTIONS

3-1. GENERAL.

3-2. This section contains instructions on how to adapt the unit to, and operate it in, a number of varied applications. These include remote sensing, remote programming and series and parallel operation.

CAUTION

The sensing and power circuits form a closed loop. Opening this loop, either by removing a terminal-board link or disconnecting a sensing or programming lead, will result in a high unit output and may damage the load or the supply.

3-3. CONTROLS.

3-4. QSA units are equipped with a single operating control, the Output Adjust potentiometer. This control is accessible through an aperture located in the nameplate end. Connected in series with the sensing network and across the output terminals, it is used to vary the unit output voltage.

3-5. PREOPERATION CONSIDERATIONS.

3-6. CURRENT/TEMPERATURE COMPENSATION. Figure 1-1 shows that the maximum safe output current is inversely proportional to ambient temperature beyond 40°C. Conversely, the value at which the current limit or foldback is set is inversely dependent of temperature.

This means that, although the safe current output may well decrease due to high ambient, the current limit foldback remains at its factory-set value (approximately 119% I rated at 50°C). In effect, this nullifies the protection which current limit foldback is designed to provide. It is therefore recommended that, if the unit is to be operated in ambients between 40 and 71°C, the current limit foldback be reset.

1-1. Compensation Calculation. The value to which the current limit foldback should be preset may be determined as follows: measure the temperature of the environment in which unit will operate. Turn to Figure 1-1 and find this point along the horizontal axis. Then extend a vertical line upwards from the point until it intersects the curve. At the intersection, extend a horizontal line to the left until it meets the vertical axis. The intersection here is the percentage of derating. Multiply this percentage by the maximum output current at 50°C (Table 1-1). Take the product and multiply by 119%, or if a temperature-compensated setting is desired, by K , where $K = 120 + \Delta T (0.1)$. The $\Delta T (0.1)$ is a compensation factor for limit-current temperature sensitivity, where ΔT is the difference between 40°C and the actual ambient, and 0.1 is the temperature coefficient. The constant 120 compensates for the crossover and drift characteristics.)

3-3. Sample Calculation. For illustrative purposes, assume a Model Q&A 10-1.1 is to be operated in an ambient of 60°C. From Figure 1-1, the derating percentage is found to be 80. The product of 7.80 and 0.8 is 6.24 A. This is the derated output. Next, multiply 6.24 A by 1.26. Current obtained is 7.86 A. For this example, 7.8 A would be used as the new current-limit value.

1-4. CURRENT-LIMIT RESET (10-watt models only). To reset the current limit, proceed as follows:

- Rotate Output Adjust fully clockwise.
- Connect a a-c ammeter (0.5% accuracy) across the output terminals. Select a 0-10 A range on meter. The ammeter is to serve as an overload measuring instrument.
- Remove side enclosure.

d. Apply nominal input power, and adjust potentiometer R6 on component board until ammeter indicates the compensated current-limit value.

e. Disconnect input power and test meter. Apply locking compound to R6, and remount enclosure.

3-10. CURRENT-FOLDBACK RESET (Model 5-6.4 only). To reset the current foldback:

a. Remove the side enclosure to expose the component board.
b. Rotate foldback adjust potentiometer R6 fully clockwise.
c. Connect a voltmeter across the output terminals. Apply nominal input voltage and adjust the output voltage with output adjust control R18 to the lower limit of the unit's specified range. Alternatively, if the supply is to be used at a fixed voltage above the lower limit, set the output voltage to the fixed value.

d. Remove the input power and connect an ammeter and a variable load resistor in series across the output terminals.

e. Reapply the input power and adjust the load resistor so that the ammeter reads the foldback current calculated in para. 3-7.

f. Rotate potentiometer R6 slowly counterclockwise until both the output voltage and current just begin to drop.

g. Remove the input power, disconnect the test equipment, apply locking compound to R6, and replace the side enclosure.

3-11. LOCAL SENSING.

3-12. The unit is shipped ready for use in the local-sensing configuration. This means that the output is regulated at the output terminals, with no compensation for load-load drops. If these drops are expected to be prohibitive, use the remote-sensing configuration as outlined in para.3-14.

3-13. To operate the unit with local sensing, proceed as follows:

a. Connect a voltmeter across OUT (1 and 4) terminals.
b. Attach input leads to IN (6 and 7) terminals. Use GRD terminal (5) for input-system ground.

- c. Apply nominal input power.
- d. Rotate Output Adjust control until desired output voltage is indicated on voltmeter.
- e. Remove input power, disconnect voltmeter and connect load leads to terminals 1 and 4. Do not remove or loosen any of the inter-connecting links. Apply nominal input. Unit supplies highly regulated voltage to load.

WARNING

Do not touch enclosure while unit is operating under load. Surface temperature is high. If unit must be handled immediately after operation, wear heat-resistant gloves.

3-14. REMOTE SENSING.

3-15. If it is desirable to sense (regulate) unit output at the load rather than at the output terminals, remove links between the SENSE and OUT terminals. Using coaxial cable for the sensing leads, connect from SENSE terminals (2 and 3) to the load (see Figure 3-1), with the shield at the negative SENSE terminal (3). Put unit into operation per para. 3-13. The unit's transient response degenerates slightly in remote-sensing operation. If this is an undesirable feature, disconnect output capacitor C7 and reconnect it, or an identical capacitor, locally across the load. Rating of C7 may be determined from parts list in Section VI.

3-16. REMOTE PROGRAMMING.

3-17. RESISTANCE. The unit may be programmed to supply predetermined output voltages by inserting a calculated resistance into the programming circuit. In calculating the resistor's value, use the ratio of 100 ± 0.5 ohms/volt, i.e., for every volt of desired output between 0 and 10, about 100 ohms should be introduced into the programming circuit.




Figure 3-1. Remote Sensing

3-18. In selecting the resistor, make certain that it is a precision type with a low temperature coefficient (± 30 ppm/ $^{\circ}\text{C}$). Programming current is 10 mA. Choose a resistor with a wattage rating at least 10 times that calculated.

3-19. To adapt unit for remote programming with remote sensing, place the precision resistor either across terminals 3 and 4 (labeled $\triangle 1$ in Figure 3-2), or in place of the jumper across component board terminal studs E5 and E6 (labeled $\triangle 2$). To gain access to component board, remove the sine panel. For remote programming with local sensing, the precision resistor is substituted for the link between terminals 3 and 4 on the terminal board. Use twisted or shielded wire for connecting resistor leads. With the resistor in place, proceed as follows:

- a. Turn Output Adjust control fully counterclockwise.




Figure 3-2. Remote Programming with Remote Sensing

- b. Apply nominal input power, and verify that the output voltage across terminals 1 and 4 is the desired value.
- c. Disconnect input power, make load connections and re-apply input. Programmed output is now supplied to load.

Note

To discontinue programming, remove input and precision resistor. If jumper or link was removed, reconnect it.

3-20. **VOLTAGE.** The unit may also be programmed to supply a constant or variable output by introducing a voltage signal into the programming circuit. The procedure is identical to that for resistance programming (para. 3-17), with this exception: instead of connecting a resistor across studs E5 and E6, connect the signal source. This source must be floating (not grounded) and the signal should have a low-noise, low-ripple content. In addition, it must be capable of absorbing the 10 mA programming current. For voltage-signal programming, the programming sensitivity is 1 volt-per-volt, i.e., the signal source must provide one volt of signal for each volt of desired output. Do not use a signal greater than 10 V (7 V if programming 5-6.4).

3-21. SERIES OPERATION.

3-22. Combinations of QSA Models may be connected in series to provide a cumulative output voltage (Table 1-1). Maximum current output is limited to the output of the lowest rated supply. Total regulation is the sum of the regulations for all units.

3-23. If, in series operation, a unit fails, reverse voltage will appear across the failed unit's output terminals and consequently may damage the output capacitor. To clamp the reverse voltage to about 1 volt, connect a rectifier across each set of output terminals used in the system. Table 3-1 lists the rectifiers recommended for series operation.

3-24. To hook two units up in series, see Figure 3-3 and proceed as follows:

- a. Remove links between the OUT (1 and 4) and SENSE (2 and 3) terminals on both units.
- b. Connect an output lead from the positive OUT terminal (Unit 1) to positive side of load.
- c. Run an output lead from the negative OUT terminal (Unit 2) to negative side of load.
- d. Connect the negative OUT terminal (Unit 1) with positive OUT terminal (Unit 2).

e. Run sensing leads from positive SENSE terminal (Unit 1) and negative SENSE terminal (Unit 2) to load. Observe polarity.

f. Connect a sensing lead from the negative SENSE terminal (Unit 1) to positive OUT terminal (Unit 2). Next, using a sensing lead, connect the positive SENSE terminal (Unit 2) to the positive OUT terminal (Unit 2).

QSA MODEL	MANUFACTURER	MFR. PART NO.	SORENSEN PART NO.
*5-6.4	Westinghouse	409 A 409 AR	26-1096-1 26-1096-9
10-1.4	Solitron	HC 67	26-1027-3
10-2.2	Solitron	2A15	26-1002-1
10-3.7	Motorola	MR 1030A	26-1006-1
* Model 5-6.4 requires mounting forward and reverse polarity rectifiers with mica washers on a 2-1/4" square, 1/32" thick aluminum heat sink. Stud size of the rectifiers is 10-32 and mounting torque is 15-20 lb-in.			

Table 3-1. Rectifier Recommendations, Series Operation

3-25. PARALLEL OPERATION.

3-26. Loads which draw currents higher than a single unit's rated output may be serviced by paralleling units. Parallel operation is based on the "master-slave" concept, i.e., the "master" unit amplifier supplies drive current to all "slave" units. (Slave unit amplifiers are disconnected during the paralleling procedure.

3-27. The number of units which may be paralleled using the master-slave approach is dependent upon the amount of current available to drive the slave unit passing stages. This current is a variable from unit-to-unit, and depends upon dissimilarities, within acceptable




Figure 3-3. Series Operation

tolerances, in component characteristics. The maximum number of units which may be paralleled is therefore a function of the master unit selected. Under the most unfavorable conditions, at least four units may be paralleled. If the tolerances in the master unit accumulate in the favorable direction, it is possible to parallel up to 15 units.

3-28. The following outlines the procedures for paralleling two units; however, the procedure need only be extended to parallel up to the maximum. Derate each unit to 90% of the maximum nominal output current. Maximum system output is the sum of the derated currents.

- a. Apply input power to master unit, and adjust output voltage to desired value.
- b. Remove input.
- c. At internal component board of slave unit, disconnect or cut jumper across studs E1 and E2.
- d. Interconnect stud E1 of this slave unit and stud E1 of the master unit. (See Figure 3-4.)
- e. Connect load leads from each unit to load. Observe polarity.
- f. If desired, remote sensing may be employed by connecting sensing leads from SENSE terminals of master unit to the load terminals, again observing polarity.
- g. Apply nominal input power to all units.

Note

System output will drop to zero if there is a discontinuity in input power to any unit, master or slave.




Figure 3-4. Parallel Operation

SECTION IV

PRINCIPLES OF OPERATION

4-1. GENERAL.

4-2. This section contains a description of the unit's operating principles, first in broad terms and then in more detail. Its function is to provide sufficient data which, when used in conjunction with the maintenance data and procedures outlined in Section V, will enable the user to logically and quickly isolate any unit malfunction.

4-3. PASSING-STAGE PRINCIPLE.

4-4. The QSA utilizes the series-passing-stage method of regulation. With this approach, a variable impedance absorbs the difference between the desired regulated output and filtered "brute-force" d-c. The variable impedance, to simplify this discussion, is assumed to be a single transistor (actually two are connected in parallel in some QSA models). Automatic regulation occurs when an output-derived error signal, fed back through amplifiers, is applied to the passing stage. Figure 4-1 is an idealization, using input and output waveforms, of passing-stage operation.

4-5. BLOCK DIAGRAM

4-6. The following brief description discusses unit operating principles in a general manner. A more detailed treatment is presented in subsequent paragraphs. Refer to Figure 4-2: the input transformer accepts an a-c input, steps down the voltage and applies it across a full-wave, center-tapped rectifier. Rectifier output is fed through a




Figure 4-1. Series Passing Stage Principle

passing stage to the load. The passing stage acts to absorb the difference between the rectifier and desired output voltage. The feedback loop to the passing stage includes a sensing and error amplifier which compares a sample of the unit's output against a fixed reference, provided by an internal reference power supply. Error signals resulting from the comparison are differentially amplified and fed to the driver. These signals are used to alter the impedance of the passing stage as a function of unit output. Short-circuit and overload protection is provided by the current-limit section.




Figure 4-2. Block Diagram

4-7. DETAILED DISCUSSION.

4-8. **REFERENCE POWER SUPPLY.** The reference power supply provides 9 volts of highly stable, precise direct current as a reference for the sensing and error-amplification section. The supply derives its power from a full-wave, center-tapped rectifier (CR6 - CR7), connected across a secondary winding of T1. Basic supply components include transistor Q5, two differential amplifiers Q6 - Q7 and Q8 - Q9, zener diode CR8 and potentiometer R15.

Note

For schematic locations of reference designations used throughout this section, see Figure 5-3.

4-9. Reference-supply output voltage is sensed across potentiometer R15, where a portion of the drop here is compared with a voltage reference developed by diode CR8. Resulting error signals are amplified and directed to the base of transistor Q5. Q5 acts as a variable impedance, increasing or decreasing the voltage drop across the stage as a function of the output voltage.

4-10. As an illustration of circuit operation, assume that an increase in reference-supply output voltage is sensed across potentiometer R15.

A portion of the sensed voltage is compared with the constant voltage developed across CR8. The resulting error signal forces Q9 into higher conduction. The current through Q9 increases, while that through Q8 decreases. (Resistor R16 acts as a current generator, pulling an approximately constant current that is the sum of the operating currents of Q8 and Q9.) Increasing current through Q9 brings about a decrease in drive current on the base of Q6. Operating current through Q6 drops, decreasing the drive to Q5. As a result, Q5 conducts less (impedance increases) and the voltage across R15 is regulated to the precise 9-volt output.

4-11. SENSING AND ERROR-AMPLIFIER SECTION. In this section, a comparison is made between the precise output from the previously described reference supply and a portion of the unit output voltage. Resulting error signals are differentially amplified and fed to the passing-stage section. Main components include output-adjust potentiometer R18, resistor R25, and differential amplifiers (Q12 - Q13 and Q10 - Q11).

4-12. As an illustrative example of circuit operation, assume that the output voltage starts to rise. The voltage across R18 increases and therefore the base of Q12 becomes more negative with respect to the base of Q13. The operating current through Q12 decreases, and the current in Q13 increases. (The increase results because the sum of the operating currents of Q12 and Q13 is held approximately constant by R24.) With a decrease of current through Q12, there is a decrease in drive on the base of Q10 (and an increase in base Q11 drive current.) Q10 therefore will go into a state of lower conduction, reducing the drive on Q1 and subsequently increasing the impedance of passing stage Q2.

4-13. DRIVERS AND PASSING STAGE. The drivers and passing stage are composed basically of two amplifiers (drivers) Q1 and Q3, and transistor Q2, connected in the positive output leg. Driver Q1 accepts a signal from differential amplifier (Q10-Q11), amplifies and then feeds it to the base of Q3. The signal is again amplified and directed to the base of Q2 where it determines Q2's conduction level, causing an increase or decrease in the absorbed voltage as a function of unit output.

4-14. CURRENT-LIMIT SECTION (10-Volt Models). The current-limit section operates to provide unit overload protection. If output current begins to increase above a preset value (determined by potentiometer R6), unit output voltage is rapidly decreased while the output current is held approximately constant. Main components include reference diode CR5, resistors R5-R6 and transistor Q4.

4-15. The section functions as follows: under normal conditions, transistor Q4 is nonconducting because of insufficient base-emitter voltage. However, as output current attempts to rise above the limiting value, the drop across R7 increases, as does the sum of the voltages across R6 and Q4 base-emitter. The voltage across R6 is held constant by CR5, and as a result, only Q4's base-emitter voltage increases. Q4 is then driven into conduction and draws current from differential amplifier Q10-Q11. As may be recalled from para. 4-12, this amplifier supplies the signal current to the drivers and passing stage, and it is this current which is rerouted. As a result, signal current to the drivers and passing stage is greatly diminished, and transistor Q2 approaches cut off. The output voltage drops as more voltage is absorbed by the passing stage and then stabilizes when the load conduction is satisfied.

4-16. CURRENT-FOLDBACK SECTION (Model 5-6.4). The current foldback section provides overload protection in the Model 5-6.4 power supply. While its purpose is the same as the current-limit circuit in the 10-volt supplies, it operates in somewhat different manner. When the load on the Model 5-6.4 exceeds a safe maximum, both the output current and the output voltage of the supply decrease in proportion to the excess of load.

4-17. Detailed circuit operation is almost identical to the operation of the current-limit circuit used in the 10-volt models - the only difference is the rearrangement of the circuit to return resistor R5 to the collector of Q4. This provides a negative feedback at the base of Q4, which tends to shift the operating point of Q4 by changing the base bias with increasing overload. The combined effect of the change in base bias and the change in voltage drop across R7A with overload cause both output current and output voltage to decrease.

4-18. REVERSE-BIAS SECTION. The reverse-bias section functions (1) during "load-off" transients to improve the response time by rapidly cutting off the passing stage and (2) to absorb "thermal effect" current generated at high junction temperature. The section is made up of a full-wave, center-tapped rectifier CR2-CR3, capacitor C4, and resistors R1, R2 and R3.

SECTION V

MAINTENANCE

5-1. GENERAL.

5-2. This section provides troubleshooting data, periodic servicing, and calibration and performance-testing procedures. The troubleshooting data should be used in conjunction with the schematic diagram (Figure 5-3) which tabulates voltage-check points, Section IV which outlines the principles of operation, and Figures 5-1 and 5-2 which physically locate the parts appearing on the schematic. Any questions pertaining to repair should be directed to the nearest Sorensen representative (a list is included with the unit) or to the Service Department, Sorensen Company, 676 Island Pond Road, Manchester, New Hampshire, 03103. Include the model and serial numbers in any correspondence. Should it be necessary to return a unit to the factory for repair, authorization from the Sorensen Service Department must be obtained first. Sorensen Company will not assume responsibility for units returned without prior authorization.

5-3. PERIODIC SERVICING.

5-4. The QSA Models require no periodic servicing. However, it is recommended that, whenever a unit is taken off the line, the enclosure be inspected and cleaned of any accumulations of dust or other debris which could impede natural air flow through unit.

5-5. TROUBLESHOOTING.

SYMPTOM	PROBABLE CAUSE
No Output	a. No input. b. User-supplied fuse blown (check for shorted rectifier CR1, CR2, CR3, CR4, CR6 or CR7⁽¹⁾ or shorted transformer winding).
High Output	a. In reference supply, Q9, Q7, or CR8 open. Q8, Q6, or Q5 shorted. Defective R15. b. Q1, Q3 or Q2 shorted ⁽²⁾. c. In sensing and error-amplification section, Q10 or Q12 shorted, or Q11 or Q13 open.
Low or Negative Output	a. In reference supply, Q9, Q7 or CR8 shorted. Q8, Q6 or Q5 open. b. Q1 or Q3 open. c. In sensing and error-amplification section, Q10 or Q12 open, or Q11 or Q13 shorted. d. In current limit section, Q4 or CR5 ⁽³⁾ shorted.
Output Ripple Degenerates	CR1 or CR4 open.
Transient Response Degenerates	CR2 or CR3 open.
(1) Complementary rectifier and transformer may be damaged. (2) When replacing Q2, apply thermal junction compound to underside of transistor. Use Thermacote, Thermalloy Co., Dallas, Texas, or an equivalent. (3) 10-volt models only.	

Table 5-1. Troubleshooting Data




Figure 5-1. Typical Component Board (QSA 10-3.7 shown)

5-6. Table 5-1 lists a number of malfunction symptoms and their probable causes. The table covers symptoms which are attributed to a single component failure only. This should not be interpreted to mean that there could not be other causes for the tabulated symptoms. Multiple failures, for instance, may give identical indications. Footnotes in the table indicate which components may be damaged due to a "chain-reaction" effect. If any amplifier components are replaced, unit may require recalibration. Refer to para 5-7.

5-7. CALIBRATION.

5-8. To calibrate a QSA supply, proceed as follows (open text applies to 10-volt models, values in parentheses apply to Model 5-6.4):

- a. Remove side enclosure.
- b. Rotate Output Adjust R18 fully clockwise (shaft is accessible at aperture located in nameplate).

QSA MODEL 10-3.7




Figure 5-2. Partial Disassembly (typical)

c. Remove nameplate, and turn bridge-voltage control R15 to center of rotation range (shaft is located directly above R18 when unit is in the normal position, i.e., with markings at terminal board right-side up).

d. Rotate current-limit control R6, located on component board, fully clockwise.

e. Remove jumper from across terminal studs E5 and E6 on component board, and then connect a precision-resistor box across studs. Set box resistance to exactly 1000 (700) ohms,

f. Connect a sensitive 0-15 (0-10) Vdc voltmeter across the OUT terminals on terminal board. At no load, apply nominal input to IN terminals.

g. Rotate bridge-voltage control R15 to obtain a voltmeter indication of 10 ± 0.05 (7 ± 0.05) volts.

h. Remove input power, disconnect resistor box and reconnect jumper across studs E5 and E6. Reconnect input.

i. At no load and nominal line, turn Output Adjust R18 from stop-to-stop. Test voltmeter should indicate a range of 0 to 10 (3-7)V.

j. With output set at 10 (7) volts, disconnect input.

k. Using load leads, connect a 10 Adc meter across the OUT terminals.

l. Rotate current-limit control R6 fully counterclockwise.

m. Apply nominal input and adjust R6 to obtain an indication of 1.85-1.95 A (QSA 10-1.4), 2.9-3.0 A (QSA 10-2.2), 4.9-5.1 A (QSA 10-3.7), or 8.7-8.9 A (QSA 5-6.4) on test ammeter.

n. Remove input. Disconnect test meters and resistance box. Apply locking compound to potentiometers R6 and R15.

o. Replace nameplate and side enclosure.

5-9. PERFORMANCE TESTING.

5-10. OUTPUT RIPPLE. To measure output ripple, proceed as follows (open text applies to 10-volt models, values in parentheses apply to Model 5-6.4):

a. Connect a test set-up as shown in Figure 5-4. Set oscilloscope for 0.5mV/cm vertical and 10ms/cm horizontal. (Oscilloscope should have at least a 30 MHz bandwidth). Select a 150-V range for a-c input voltmeter. Choose a 0.5mV range for RMS meter and a 5 (10) Arange for a-c ammeter. Use a resistive load with a working current rating




Figure 5-4. Performance Test Setup

of at least 0.10 A. Use the differential voltmeter as a VTVM. Select a 10 (10) volt range.

b. With no load, apply a 115 Vac, 60 Hz input, and adjust output to 10 (10) volts.

c. Apply full load and observe oscilloscope and RMS voltmeter. Voltmeter should indicate no more than 0.1 mV; oscilloscope should display a peak-to-peak voltage no greater than 4 mV.

d. If needed, check regulation per para. 5-11.

5-11. REGULATION. To measure unit's output regulation, proceed as follows (open text applies to 37-watt models, value in parentheses applies to Model 5-6.4):

a. Connect unit to test set-up shown in Figure 5-4. The oscilloscope and RMS voltmeter are not necessary. Use the multimeter in the differential mode. Select an internal voltage equal to 10 (14) volts, and set null sensitivity to the 10 mV range.

b. Apply a 115 Vac, 60 Hz input, and adjust output voltage to obtain a null indication on voltmeter.

c. With a-c multimeter indicating 115 Vac, increase load on unit until a-c ammeter reads 7 A (QSA 5-6.4), 1.64 A (QSA 11-1.4), 1.4 A (QSA 10-1.1) or 4.0 A (QSA 10-1.7). Record the deviation from voltmeter null position.

d. Adjust voltmeter internal voltage to regain the null position. Then, with full load on unit, vary unit input voltage at 60 Hz from 100 to 125 Vac. Note the deviation.

e. Sum the deviations recorded on steps c and d. The total should be less than 1 mV (not greater than 0.5 mV).

SECTION VI

REPLACEMENT PARTS LIST

6-1. GENERAL.

6-2. This section provides replacement parts lists for the QSA power supplies. The lists are keyed to both the schematic diagram (Figure 5-3) and the parts-locating photographs (Figures 5-1 & 5-2). Table 6-1 lists parts for the QSA 10-volt models: Table 6-2 shows the parts for QSA model 5-6.4

6-3. MANUFACTURER CODING.

6-4. The column headed MANUFACTURER CODE contains a listing of letter designators which, when applied to the tabulation that follows, will give the manufacturer from whom a particular item may be purchased. If no manufacturer's part number is listed in the MANUFACTURER PART NO. column, the part may be ordered from the indicated manufacturer by using the Sorensen part number and a complete description of the item.

AB	Allen Bradley Company
AX	Aerovox Corporation
CB	Centralab, Div. of Globe Union, Inc.
CS	Clarostat Mfg. Co., Inc.
CTS	CTS Inc.
FC	Fairchild Semiconductor
GE	General Electric Co.
IRC	International Resistance Co.
MA	Motorola Semiconductor Products
OM	Ohmite Mfg. Co.

RCA	Radio Corporation of America
RS	Sorensen Company
SC	Semicon, Inc.
SE	Seacor, Inc.
SP	Sprague Electric Company
ST	Solitron Devices, Incorporated
Wt	Westinghouse Electric Corp.
WL	Ward Leonard Electric Company

6-5. ORDERING PARTS.

6-6. When ordering parts from Sorensen Company, include manufacturer's part number, the Sorensen part number and the unit model number. Address orders to:

Sorensen Company
676 Island Pond Road
Manchester, New Hampshire 03103

REF DES.	DESCRIPTION	SORENSEN PART NO.	MANUFACTURER	
			PART NO.	CODE
C1,2	Cap., 4.7 nF, 200 Vdc	24-2409-5		AX*
C3	Cap., 1.4 mF, 25 Vdc	24-2452-5		SP*
	Cap., 3.4 mF, 25 Vdc	24-2544-2		SP ~~≠~~
	Cap., 6.7 mF, 30 Vdc	24-2444-4		SP+
C4	Cap., 200 μF, 15 Vdc	24-2278-17		SP
C5	Cap., 4.7 nF, 200 Vdc	24-2409-5		AX
C6	Cap., 100 μF, 25 Vdc	24-2279-14		SP
C7	Cap., 650 μF, 25 Vdc	24-2452-2		SP*
	Cap., 1 mF, 25 Vdc	24-2452-4		SP ~~≠~~
	Cap., 2 mF, 20 Vdc	24-2455-1		SP+
C8	Cap., 10 nF, 200 Vdc	24-2409-7		AX
C9,13	Cap., 22 nF, 200 Vdc	24-2409-9		AX
C10	Cap., 4 μF, 50 Vdc	24-2280-4		SP
C11	Cap., 2.2 nF, 200 Vdc	24-2409-3		AX
C12	Cap., 6.8 nF, 200 Vdc	24-2409-6		AX
C14,15	Cap., 15 nF, 200 Vdc	24-2409-8		AX
C16,17	Cap., 150 nF, 200 Vdc	24-2409-14		AX+, ~~≠~~
C18	Cap., 15 μF, 12 Vdc	24-2276-9		SP
C19	Cap., 10 nF, 50 V	24-2014		CB
CR1,4	Rectifier	26-1027-4	HC68	ST*
		26-1006-2	MR 1031A	MA ~~≠~~ ,+
CR2,3, 6,7	Rectifier	26-158-1	CER 68	ST
CR5,8	Rectifier	26-211	1N750A	MA
CR9	Rectifier	26-1006-1	MR 1030A	MA ~~≠~~ ,+
* Used on QSA Model 10-1.4 only. ~~≠~~ Used on QSA Model 10-2.2 only. + Used on QSA Model 10-3.7 only.				

Table 6-1. Replacement Parts List (10-Volt Models)(Sheet 1 of 3)

REF DES.	DESCRIPTION	SORENSEN PART NO.	MANUFACTURER	
			PART NO.	CODE
Q1	Transistor	18-145	RT 9343	RS
Q2a	Transistor	18-151	2N3055	RCA
Q2b	Transistor	18-151	2N3055	RCA ~~≠~~ , +
Q3	Transistor	18-142	40312	RCA
Q4,6,7, 8,9,12, 13	Transistor	18-144	FSC 3641	FC
Q5	Transistor	18-146	RT 9338	RS
Q10,11	Transistor	18-143	2N3638	FC
R1	Res, 47k ohm, 1/2 W	27-112	EB 4731	AB
R2	Res, 1.8k ohm, 1/2 W	28-729	GB 1821	AB
R3	Res, 180 ohm, 5 W	27-1521	5XM	WL
R4	Res, 680 ohm, 1 W	28-701	GB 6811	AB
R5,19,24	Res, 680 ohm, 1/2 W	27-156	EB 6811	AB
R6	Pot., 400 ohm, 2 W	29-489	HC-110	CTS
R7a	Res, 0.64 ohm, 3 W	27-1517		WL*
	Res, 1.0 ohm, 3 W	27-397-25		WL ~~≠~~
	Res, 0.47 ohm, 3 W	27-1516		WL+
R7b	Res, 1.0 ohm, 3 W	27-397-25		WL ~~≠~~
	Res, 0.47 ohm, 3 W	27-1516		WL+
R8	Res, 120 ohm, 1/2 W	27-1107	EB 1211	AB
R9	Res, 220 ohm, 1/2 W	27-101	EB 2211	AB
R10	Res, 390 ohm, 1 W	28-703	GB 3911	AB
R11	Res, 47 ohm, 1/2 W	27-181	EB 4701	AB
R12	Res, 820 ohm, 1/2 W	27-182	EB 8211	AB
R13	Res, 221 ohm, 1/2 W	28-1188		IRC
* Used on Model 10-1.4 only. ~~≠~~ Used on Model 10-2.2 only. + Used on Model 10-3.7 only				

Table 6-1. Replacement Parts List (10-Volt Models)(Sheet 2 of 3)

REF DES.	DESCRIPTION	SORENSEN PART NO.	MANUFACTURER	
			PART NO.	CODE
R14,16, 17	Res, 1.8k ohm, 1/2 W	27-176	EB 1821	AB
R15	Pot., 2k ohm, 4 W	29-486		RS
R18	Pot., 1.1k ohm, 4 W	29-488		RS
R20	Res, 390 ohm, 1/2 W	27-1109	EB 3911	AB
R21,23	Res, 2.7k ohm, 1/2 W	29-174	EB 2721	AB
R22	Res, 120 ohm, 1/2 W	27-1107	EB 1211	AB
R25	Res, 887 ohm, 1/2 W	28-1216		IRC
R26	Res, 0.2 ohms	190-3636		RS
R30	Res, 1k ohm, 1/4 W	27-1305	CB 1021	AB
T1	Transformer	126-2889		RS*
		126-2890		RS ~~+~~
		126-2891		RS+
*	Used on Model 10-1.4 only.			
~~+~~	Used on Model 10-2.2 only.			
+	Used on Model 10-3.7 only.			

Table 6-1. Replacement Parts List (10-volt Models) (Sheet 3 of 3)

REF DES	DESCRIPTION	SORENSEN PART NO.	MANUFACTURER PART NO.	CODE
C1,2	Cap., 50 nF, 500 Vdc	24-2010		CB
C3	Cap., 17 mF, 20 Vdc	24-2459-3		SP
C4	Cap., 200 μ F, 15 Vdc	24-2278-17		SP
C5	Cap., 4.7 nF, 200 Vdc	24-2409-5		AX
C6	Cap., 100 μ F, 25 Vdc	24-2279-14		SP
C7	Cap., 2 mF, 20 Vdc	24-2455-1		SP
C8	Cap., 10 nF, 250 Vdc	24-2015-1		SE
C9,13	Cap., 22 nF, 200 Vdc	24-2409-9		AX
C10	Cap., 4 μ F, 50 Vdc	24-2280-4		SP
C11	Cap., 2.2 nF, 200 Vdc	24-2409-3		AX
C12	Cap., 6.8 nF, 200 Vdc	24-2409-6		AX
C14,15	Cap., 15 nF, 200 Vdc	24-2409-8		AX
C18	Cap., 15 μ F, 12 Vdc	24-2276-9		SP
C19	Cap., 2 nF, 500 Vdc	24-2023		CB
CR1,4	Rectifier	26-1096-2		WH
CR2,3, 6,7	Rectifier	26-158-1		SC
CR8	Zener Diode	26-211		MA
Q1	Transistor, NPN	18-115	2N697	GE
Q2a,b	Transistor, NPN	18-151		RCA
Q3	Transistor, NPN	18-142		RCA
Q4, 6-9, 12,13	Transistor, NPN	18-144		FC
Q5	Transistor, PNP	18-146	RT 9338	RS
Q10,11	Transistor, PNP	18-143		FC
R1	Res., 47k ohm, 1/2 W	27-112	EB 4731	AB
R2	Res., 1.8k ohm, 1 W	28-729	GB 1821	AB
R3	Res., 180 ohm, $\pm$ 5%, 5 W	27-1521		WL

Note: Resistor tolerance $\pm$ 10% unless otherwise specified.

Table 6-2. Replacement Parts List (Model 5-6.4)(Sheet 1 of 2)

REF DES	DESCRIPTION	SORENSEN PART NO.	MANUFACTURER	
			PART NO.	CODE
R5,14, 16,17	Res., 1.8k ohm, 1/2 W	27-176	EB 1821	AB
R6	Pot., 400 ohm, $\pm 20\%$, 3 W	29-489		CTS
R7 a,b	Res., .27 ohm, $\pm 5\%$, 10 W	27-1530		IRC
R8,22	Res., 120 ohm, 1/2 W	27-1107	EB 1211	AB
R9	Res., 220 ohm, 1/2 W	27-101	EB 2211	AB
R10	Res., 390 ohm, 1 W	28-703	GB 3911	AB
R11	Res., 47 ohm, 1/2 W	27-181	EB 4701	AB
R12	Res., 820 ohm, 1/2 W	27-182	EB 8211	AB
R13	Res., 221 ohm, $\pm 1\%$, 1/2 W	28-1188		IRC
R15	Pot., 2k ohm, 4 W	29-486		CS
R18	Pot., 750 ohm, 4 W	29-545		CS
R19,24	Res., 680 ohm, 1/2 W	27-156	EB 6811	AB
R20	Res., 390 ohm, 1/2 W	27-1109	EB 3911	AB
R21,23	Res., 2.7k ohm, 1/2 W	27-174	EB 2721	AB
R25	Res., 887 ohm, $\pm 1\%$, 1/2 W	27-1216		IRC
R26	Res.Assembly, .4 ohm	190-3907		RS
R30	Res., 1k ohm, 1/4 W	27-1305		OM
T1	Transformer	126-3045		RS

Note: Resistor tolerance is $\pm 10\%$ unless otherwise specified.

Table 6-2. Replacement Parts List (Model 5-6.4)(Sheet 2 of 2)

Sorensen
POWER SUPPLIES

www.manualsplus.com



1006684